

FITTING INSTRUCTIONS

VEHICLE Toyota Land Cruiser 76 / 78 / 79 Series

PRODUCT Rear Locker Guard

PN# SB059

REAR LOCKER GUARD TO SUIT TOYOTA LAND CRUISER 76/78/79 SERIES

IMPORTANT NOTE BEFORE INSTALLATION

Ensure Vehicle is on level ground. Chock front wheels to avoid vehicle rolling.

TOOLS REQUIRED

- 12mm and 14mm socket
1. Remove the (3) original hardware and remove original guard.
See figure 1
 2. Remove white plug from bracket.
 3. Fit Blackhawk locker guard.
 - a. Reuse the 2 nuts previously removed.
 - b. Fit supplied M8 bolt.
 - c. Clip wiring plug into upper hole, as highlighted in figure 2.

