

FITTING INSTRUCTIONS

PRODUCT Orbiit Winch Pulley Ring -
Replacement of PTFE lined bush

PN# BH-TO Bush

NOTE Use adequate eye protection when using tools.

ORBIIT WINCH PULLEY RING REPLACEMENT OF PTFE LINED BUSH

IMPORTANT NOTE BEFORE INSTALLATION

Suggest Fitment By Mechanic.

TOOLS REQUIRED

- Circlip Pliers / Screwdriver
- Shop Press

HARDWARE SUPPLIED

- 1 x PTFE Lined Bush

1. Remove circlip holding black machined centre section and chrome spacer. Set aside in methodical order for re-assembly. See image 1 & 2
2. Use an appropriate tool to remove PTFE lined bush (shop press / hammer and chisel) taking care not to score the red anodized aluminium outer ring.
3. Re-assemble following the reverse order.
4. Re-install PTFE lined bush.
5. Place centre black section back in the housing.
6. Re install chrome spacer and circlip, installation is now complete.

