

TECHNICAL BULLETIN

JAN 20
TAP126

SBO64 - NP300 NAVARA REAR SHOCK GUARD FITTING GUIDE

1. Remove the lower shock absorber bolt.
2. Remove the upper trailing arm bolt (be advised to only remove 1 upper trailing arm bolt at a time).
See figure 1
3. Fit Shock Guard to vehicle, refit shock absorber in the OE location with the OE bolt.
4. Refit the OE upper trailing arm bolt through the shock guard.
See figure 1
5. Fit supplied M14 Bolt, washers & nut to the upper rear-most hole on the shock mount.
See figure 2
6. Fit supplied M12 bolt, washers and nut to the under-side of the shock mount.
See Figure 3
7. Repeat Step 1 to Step 6 on other side.
8. Tighten all bolts at road height.
9. Cycle suspension travel to ensure there is no interference with other components on the vehicle.

Figure 1



Figure 2



Figure 3



PLEASE NOTE

The hole in this stone guard has not been engineered to take load in its current configuration. DO NOT USE.

